

OPEN ELEMENT IAT SETTINGS

Thank you for using the open element air temperature sensor from MS Labs. To calibrate the sensor for your ECU:



- 1. Open your project
- 2. Go online
- 3. Click Tools \rightarrow Calibrate Thermistor Tables
- 4. Select Air Temperature Sensor
- 5. Select 3 Point Therm Generator
- 6. From the "Commong Sensor Values" list, select the "empty" option that faintly reads "Select a Common Sensor".
- 7. Input 2490 in the "Bias Resistor Value" box.
- 8. Select Celcius (even if you are going to use Fahrenheit later on in your project.
- 9. Input the values as shown below and then click Write to controller.

R.	Calibrate Thermistor Tables			~	\sim	^	×
Calibrate Thermistor Tables							
Sensor Table							
Air Temperature Sensor							•
Table Input Solution							
3 Point Therm Generator							•
Thermistor Measurements							
Common Sensor Values Select a Common Sensor							•
	Bias Resistor Value (Ohms)			2	490	0.0	
Fahrenheit		Celsius					
	Temperature(°C)	Resistance (Ohms))				
	20.0	2350.0					
	50.0	800.0					
	80.0	340.0					
Select settings, click "Write to Controller"							
Write to Controller							
					(Clos	e